

RAPTOR

SPECIFICATIONS

HEADSIZE sq. in.	102
HEADSIZE sq. cm.	660
LENGTH	695 mm
WEIGHT (UNSTRUNG)	285 g
BALANCE (UNSTRUNG)	330 mm
FRAME HEIGHT	2 4

SWING STYLE INDEX	4.9
--------------------------	------------

STRINGING INSTRUCTIONS

STRINGING PATTERN	16/19
--------------------------	--------------

RECOMMENDED STRING TENSION (KG)	24 ±2
--	--------------

RECOMMENDED STRING TENSION (LBS)	53 ±5
---	--------------

MAXIMUM STRING TENSION (KG)	28
------------------------------------	-----------

MAXIMUM STRING TENSION (LBS)	62
-------------------------------------	-----------

RECOMMENDED STRING	PACIFIC POWER LINE
---------------------------	---------------------------

MIN. STRING LENGTH	11.5 M
---------------------------	---------------

MIN. STRING LENGTH	37.73 FT
---------------------------	-----------------

SHORT STRING	3.0 M
---------------------	--------------

MAIN STRINGS


Always installed first. Start in the middle, and alternate the installation from side to side. Install not more than 2-main's per side before switching sides. Pull tension on each string where it exists the head, and throat areas. Tie-off string on shown holes before starting the cross strings. If main strings end at the throat, 2-piece stringing is advised. Racquets are improperly strung when the crosses are started at the bottom/throat area, and automatically void any PACIFIC warranty.

CROSS STRINGS

Always begin at the top of the racquet. For 1-piece stringing where the main strings ended at the top, begin the first cross string where shown on the corresponding diagram. For 2-piece stringing, tie-off the starting cross string on the opposite/same number hole as the short-side main string was tied-off. Begin the cross string installation from the top of the racquet and pulling tension on each cross string after weaving to the other side of the racquet frame. Tie-off the cross string at the shown hole in the throat area.

Remember!

Strings are the most important aspect to make any racquet perform at its best. Strings loose tension and resiliency even if not played. PACIFIC recommends that you string your racquet a minimum of 3-times per year, or after 30-hours of play. To insure the best performance, use only PACIFIC strings! We encourage you to seek-out a Qualified Racquet Technician who uses a PACIFIC Stringing Machine. PACIFIC is the Official String, Grip, and Stringing Machine of the ATP World Tour.



FISCHER
TECHNOLOGY

R A P T O R

SS	Short Side
T	Throat
H	Head

