

#### **SPECIFICATIONS**

107
690
695 mm
275 g
340 mm
2 5

## SWING STYLE INDEX 4.

### STRINGING INSTRUCTIONS

STRINGING PATTERN	16/20
RECOMMENDED STRING TENSION (KG)	25 ±2
RECOMMENDED STRING TENSION (LBS)	55 ±5
MAXIMUM STRING TENSION (KG)	28
MAXIMUM STRING TENSION (LBS)	62

RECOMMENDED	PACIFIC
STRING	POWER LINE

MIN. STRING LENGTH	12.0 M
MIN. STRING LENGTH	39,37 FT
SHORT STRING	3.2 M

# MAIN STRINGS

Always installed first. Start in the middle, and alternate the installation from side to side. Install not more then 2-main's per side before switching sides. Pull tension on each string where it exists the head, and throat areas. Tie-off string on shown holes before starting the cross strings. If main strings end at the throat, 2-piece stringing is advised. Racquets are improperly strung when the crosses are started at the bottom/throat area, and automatically void any PACIFIC warranty.

### **CROSS STRINGS**

Always begin at the top of the racquet. For 1-piece stringing where the main strings ended at the top, begin the first cross string where shown on the corresponding diagram. For 2-piece stringing, tie-off the starting cross string on the opposite/same number hole as the short-side main string was tied-off. Begin the cross string installation from the top of the racquet and pulling tension on each cross string after weaving to the other side of the racquet frame. Tie-off the cross string at the shown hole in the throat area.

## Remember!

Strings are the most important aspect to make any racquet perform at its best. Strings loose tension and resiliency even if not played. PACIFIC recommends that you string your racquet a minimum of 3-times per year, or after 30-hours of play. To insure the best performance, use only PACIFIC strings! We encourage you to seek-out a Qualified Racquet Technician who uses a PACIFIC Stringing Machine. PACIFIC is the Official String, Grip, and Stringing Machine of the ATP World Tour.







